



ALL OCCASIONS  
EVENT RENTAL

10629 READING ROAD • EVENDALE • 513-563-0600



# GRILL

## DIRECTIONS

### TO IGNITE BURNERS

1. Make sure all burners are in the "OFF" position.
2. Rotate tank valve counter clockwise to allow gas to enter the burner system.
3. Totally withdraw the grease tray(s).
4. Open hood cover. Open the burner gas valve by rotating the burner control clockwise 1/4th of a turn. **IMPORTANT:** wait 3 seconds after opening gas valve before lighting.
5. From underneath the burner, apply open flame to side of burner; for best results ignite with an automatic fire stick, otherwise use 6 inch fireplace matches.
6. Repeat this process for the ignition of each burner desired.

**DO NOT LIGHT ONE BURNER AND SIMPLY TURN ON THE REMAINING BURNERS...THIS MAY RESULT IN AN EXPLOSION.**

### TO TURN OFF

1. To ensure safety, always shut off the tank valve first to allow the burners to burn out.
2. Tightly close the burner control levers by rotating counter clockwise; this will ensure no gas remains in the gas manifold, gas hoses and/or regulator.

**IF YOU EXPERIENCE ANY PROBLEMS CALL 513-563-0600**

**24 HOUR EMERGENCY SERVICE**